




		NTX 350 1987-1990		GU056		00		TAB N.		01	
BATTERY											
											
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.			
1	Battery 12V-24AH	-	-	-	F	-	GU20704552	1			
2	Float chamber	-	-	-	-	-	GU14707000	1			
3	Cap	-	-	-	-	-	GU23707100	1			
4	Plate	-	-	-	-	-	GU27704815	1			
5	Spacer	-	-	-	-	-	GU91180605	2			
6	Spacer	-	-	-	-	-	GU91180721	4			
7	HT coil	-	-	-	N	-	GU31716560	2			
8	Screw	-	-	-	-	-	GU98620240	4			
9	Spacer	-	-	-	-	-	GU91180716	4			
10	Ring nut	-	-	-	-	-	GU19741336	1			
11	Bosch rectifier	-	-	-	-	-	GU17704300	1			
12	Cover	-	-	-	-	-	GU61704200	1			
13	Connector SAPRISA	-	-	-	-	-	GU28712500	1			
14	Washer 6,4x12x1,2	-	-	-	-	-	GU95100141	2			
15	Nut	-	-	-	-	-	GU92601208	1			
16	Spring washer 5,3X10X0,5	-	-	-	-	-	GU95129100	6			
17	Nut	-	-	-	-	-	GU92602205	4			
18	Voltage regulator BOSCH	-	-	-	-	-	GU29703800	1			
19	Washer	-	-	-	-	-	GU95007208	2			
20	Screw	-	-	-	-	-	GU98052245	4			
21	Screw	-	-	-	-	-	GU98054214	2			
22	Voltage regulator SAPRISA	-	-	-	S	-	GU28703800	1			
23	Main switch	-	-	-	-	-	GU31735360	1			
24	Screw	-	-	-	-	-	GU98290512	2			
25	Washer	-	-	-	-	-	GU95000205	2			
26	Phase/revolution sensor	-	-	-	-	-	GU29722270	1			
27	Screw	-	-	-	-	-	GU92622318	1			
29	Rotor	-	-	-	-	-	GU27721037	1			
30	Notched washer	-	-	-	-	-	GU95021105	3			
31	Repairing kit	-	-	-	-	-	GU17712454	1			
32	Screw	-	-	-	B	-	GU14712459	1			
33	Cap	-	-	-	-	-	GU14717600	2			
34	Wire	-	-	-	-	-	GU19748000	2			

35	Cap	-	-	-	-	-	GU19707100	2
36	Hose clamp 3,6x20,6	-	-	-	-	-	GU14609650	20
37	Hex socket screw M5X45	-	-	-	B	-	GU98620245	3
38	Screw	-	-	-	-	-	GU98072435	2
39	Sparkplug cap NGK	-	-	-	-	-	GU30717410	2
40	Spark plug CW8LP	-	-	-	M	-	GU19717001	2
	Spark plug NGK B8ES	-	-	-	-	-	GU31717060	2
41	Bosch alternator	-	-	-	B	-	GU17712400	1
42	Protection	-	-	-	B	-	GU19733350	1
43	Starter motor Valeo	-	-	-	V	-	GU30730711	1
44	Starter motor revision kit	-	-	-	B	-	GU14730570	1
	Starter motor revision kit	-	-	-	L	-	GU19730580	1
45	Hex screw M6X20	-	-	-	-	-	GU98054320	2
46	Notched washer	-	-	-	-	-	GU95021106	2
47	Washer	-	-	-	-	-	GU95000206	2
48	Nut	-	-	-	-	-	GU92602206	2
49	Generator SAPRISA	-	-	-	S	-	GU28712400	1
50	Screw	-	-	-	S	-	GU98620250	3
51	Screw	-	-	-	S	-	GU28712459	1

NTX 350 1987-1990

GU056


00


TAB N.

02

FAIRING

Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Windshield	-	-	-	- gr	GU275754151	1	
2	Windscreen	-	-	-	-	GU27577215	1	
3	Winndshield support	-	-	-	-	GU27578615007	1	
4	Gasket PVC	-	-	-	-	GU00823931080	1	
5	Hex socket screw M6X12	-	-	-	-	GU98682312	2	
6	Notched washer	-	-	-	-	GU95021106	2	
7	Washer	-	-	-	-	GU95000206	2	
8	Screw	-	-	-	-	GU98822420	1	
9	Spring washer	-	-	-	-	GU95021108	1	
10	Washer	-	-	-	-	GU95000208	1	
11	Captive nut	-	-	-	-	GU92660601	2	
12	Screw	-	-	-	-	GU98326014	2	
13	Washer 6,25X11X1	-	-	-	-	GU95100119	2	
14	Screw	-	-	-	-	GU98230618	6	
15	Special washer	-	-	-	-	GU61013800	6	
16	Clip	-	-	-	-	GU92680060	4	
17	Screw	-	-	-	-	GU98260416	4	
	Screw	-	-	-	A	GU99210316	4	
18	Washer	-	-	-	-	GU14577850	4	
19	O-ring	-	-	-	-	GU90706035	4	
20	Nut	-	-	-	-	GU27576015	4	
	Threaded insert	-	-	-	A	GU27576016	4	
21	Gasket PVC	-	-	-	-	GU00823931080	1	

		NTX 350 1987-1990		GU056		00		TAB N.		03	
BODY											
											
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.			
1	Fuel tank	-	-	-	-	gr GU271002151	1				
2	Fuel filler cap	-	-	-	-	GU66103915	1				
3	Breather pipe	-	-	-	-	GU66109715	1				
4	Union	-	-	-	-	GU66101815	2				
5	Ring	-	-	-	-	GU90706204	2				
6	RH fuel cock	-	-	-	-	GU27105410	1				
7	RH fuel cock	-	-	-	-	GU27105410	1				
8	Fuel pipe	-	-	-	-	GU29106500	1				
9	Hose clamp	-	-	-	-	GU61108400	2				
10	Hose clamp D9	-	-	-	-	GU61108500	2				
11	Plate	-	-	-	-	GU27103515	1				
12	Rubber spacer	-	-	-	-	GU27103415	2				
13	Saddle	-	-	-	-	GU27460515	1				
14	Clamp	-	-	-	-	GU27460910	1				
15	Clamp	-	-	-	-	GU27460911	1				
16	Spacer	-	-	-	-	GU91180605	2				
17	Knob	-	-	-	-	GU27462910	2				
18	Captive nut	-	-	-	-	GU92660601	21				
19	Rear fairing	-	-	-	-	gr GU274664101	1				
	Rear fairing	-	-	-	-	b-r GU27466416	1				
	Rear fairing	-	-	-	-	b-gg-r GU27466417	1				
	Rear fairing	-	-	-	-	b-g-n GU27466418	1				
20	RH side panel	-	-	-	-	gr GU274762151	1				
21	Rubber spacer	-	-	-	-	GU91551085	4				
22	Nylon washer 6X17X1	-	-	-	-	GU66478610	2				
23	Screw	-	-	-	-	GU98326016	2				
24	LH side panel	-	-	-	-	gr GU274763151	1				
25	Decal set	-	-	-	-	b GU27923315	1				
27	Screw	-	-	-	-	GU98250516	2				
28	Screw M8X30	-	-	-	-	GU98622430	1				
29	Captive nut	-	-	-	-	GU92660801	1				
30	Hex screw M6X16	-	-	-	-	GU98054316	4				
31	Notched washer	-	-	-	-	GU95021106	4				
32	Washer	-	-	-	-	GU95101140	4				

		NTX 350 1987-1990		GU056	00	TAB N.	04	
		BEVEL GEAR						
								
Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Transmission cover	-	-	-	-	GU31350331	1	
2	Clearance washer	-	-	-	-	GU19351900	1	
3	Gasket ring	-	-	-	-	GU70403547	11	
4	Clearance washer	-	-	-	-	GU19351100	1	
5	Roller bearing 35x50x17	-	-	-	-	GU92252235	1	
6	Oil filler plug	-	-	-	-	GU31351200	1	
7	O-ring 20,24X2,62	-	-	-	-	GU90706203	1	
8	Plug	-	-	-	-	GU95980611	1	
9	Gasket	-	-	-	-	GU10528900	1	
10	Breather plug	-	-	-	-	GU31206500	1	
11	Gasket	-	-	-	-	GU10528900	1	
12	Stud bolt	-	-	-	-	GU96508055	1	
13	Cover	-	-	-	-	GU27350410	1	
14	Ball bearing 70x110x13	-	-	-	-	GU92201070	1	
15	Gasket ring 75x90x8	-	-	-	-	GU90407590	1	
16	Pin	-	-	-	-	GU19351402	1	
17	Stop ring	-	-	-	-	GU90353030	1	
18	Bevel gear Z=8/31	-	-	-	-	GU20354621	1	
19	Screw	-	-	-	-	GU19356320	6	
20	Tap.roller bearing	-	-	-	-	GU92249223	1	
21	Spacer 1,1 mm	-	-	-	-	GU19355406	1	
	Spacer 1,6 mm	-	-	-	-	GU19355413	1	
	Spacer 1,5 mm	-	-	-	-	GU19355412	1	
	Spacer 1,4 mm	-	-	-	-	GU19355411	1	
	Spacer 1,2 mm	-	-	-	-	GU19355408	1	
	Spacer 1 mm	-	-	-	-	GU19355404	1	
	Spacer 0,9 mm	-	-	-	-	GU19355402	1	
	Spacer 0,8 mm	-	-	-	-	GU19355400	1	
	Spacer 1,3 mm	-	-	-	-	GU19355410	1	
22	Gasket	-	-	-	-	GU19350700	2	
23	Thrust washer	-	-	-	-	GU19352300	1	
24	Thrust washer	-	-	-	-	GU19353500	1	
25	Screw M8X25	-	-	-	-	GU19357660	7	

26	Spring washer 8x15x0,3	-	-	-	-	-	GU61270300	7
28	Spacer	-	-	-	-	-	GU19356801	1
29	Gasket ring 18,77X1,78	-	-	-	-	-	GU90706188	1
30	Nut	-	-	-	-	-	GU19356700	1
31	Bearing casing	-	-	-	-	-	GU19352401	1
32	Roller bearing 20x47x14	-	-	-	-	-	GU92249220	1
33	Spacer 1,1 mm	-	-	-	-	-	GU19355301	2
	Spacer 1,8 mm	-	-	-	-	-	GU19355308	2
	Spacer 1,7 mm	-	-	-	-	-	GU19355307	2
	Spacer 1,6 mm	-	-	-	-	-	GU19355306	2
	Spacer 1,5 mm	-	-	-	-	-	GU19355305	2
	Spacer 1,4 mm	-	-	-	-	-	GU19355304	2
	Spacer 1,2 mm	-	-	-	-	-	GU19355302	2
	Spacer 1,9 mm	-	-	-	-	-	GU19355309	2
	Spacer 1 mm	-	-	-	-	-	GU19355300	2
	Spacer 1,3 mm	-	-	-	-	-	GU19355303	2
34	Spacer	-	-	-	-	-	GU19355121	1
35	Shim 0,1 mm	-	-	-	-	-	GU19355200	1
36	Shim 0,15 mm	-	-	-	-	-	GU19355202	1
37	Gasket ring	-	-	-	-	-	GU90706552	1
38	Gasket ring	-	-	-	-	-	GU90403247	1
39	Spacer	-	-	-	-	-	GU27634110	2
40	Spacer 1,1 mm	-	-	-	-	-	GU19355321	1
	Spacer 1,9 mm	-	-	-	-	-	GU19355329	1
	Spacer 1,8 mm	-	-	-	-	-	GU19355328	1
	Spacer 1,7 mm	-	-	-	-	-	GU19355327	1
	Spacer 1,6 mm	-	-	-	-	-	GU19355326	1
	Spacer 1,5 mm	-	-	-	-	-	GU19355325	1
	Spacer 1,4 mm	-	-	-	-	-	GU19355324	1
	Spacer 1,2 mm	-	-	-	-	-	GU19355322	1
	Spacer 1 mm	-	-	-	-	-	GU19355320	1
	Spacer 1,3 mm	-	-	-	-	-	GU19355323	1
41	Plate	-	-	-	-	-	GU27357411	1

NTX 350 1987-1990

GU056

00

TAB N.

05

DASHBOARD

Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Dashboard lower support	-	-	-	-	GU31501635	1	
2	Speedometer	-	-	-	-	GU27761515	1	
3	Gear 60°	-	-	-	-	GU23768310	1	
4	Tachometer	-	-	-	-	GU27767215	1	
5	Panel with lenses	-	-	-	-	GU63766920	1	
6	Lampholder	-	-	-	-	GU14768650	2	
7	Lamp 12v-3w	-	-	-	-	GU93450120	2	
8	Blinker indicator light holder	-	-	-	-	GU65758970	2	
9	Lampholder	-	-	-	-	GU19768680	7	
10	Turn indicator switch	-	-	-	-	GU28745760	1	
11	Rev counter transmission	-	-	-	-	GU27768185	1	
12	Speedometer transmission	-	-	-	-	GU27760410	1	
13	Gear Z=14	-	-	-	-	GU14769200	1	
14	Speedometer gear	-	-	-	-	GU27762510	1	

NTX 350 1987-1990	GU056	00	TAB N.
HEADLIGHT-HORN			

06

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Headlight	-	-	-	-	GU27740515	1	
2	Lamp 12V 45/40W	-	-	-	-	GU93450231	1	
3	Lamp 12V-5W	-	-	-	-	GU93450105	1	
4	Lampholder	-	-	-	-	GU14768650	1	
5	Rear turn indicator	-	-	-	-	GU27751611	2	
6	Turn indicator lens	-	-	-	-	GU28753750	2	
7	Lamp 12V-10W	-	-	-	-	GU93450129	2	
8	Turn sig. support rod	-	-	-	-	GU27751315	2	
9	Front LH turn indic supp.cpl.	-	-	-	-	GU27753216	1	
10	Spacer	-	-	-	-	GU27753415	2	
11	Notched washer	-	-	-	-	GU95022110	2	
12	Nut	-	-	-	-	GU92602411	2	
13	Front RH turn indic supp.cpl.	-	-	-	-	GU27753215	1	
14	Horn	-	-	-	-	GU27743715	1	
15	Hex screw M6X22	-	-	-	-	GU98054322	1	
16	Notched washer	-	-	-	-	GU95021106	1	
17	Nut	-	-	-	-	GU92602206	1	
18	Hex screw M6X22	-	-	-	-	GU98054322	2	
19	Washer 6,4x12x1,2	-	-	-	-	GU95100141	2	
20	Washer 5,3x10x0,5	-	-	-	-	GU95100121	2	
21	Nut M6x1	-	-	-	-	GU92630106	2	

NTX 350 1987-1990	GU056	00	TAB N.
TAILLIGHT			

07

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Stud bolt	-	-	-	-	GU27742010	1	
2	Taillight	-	-	-	-	GU27740911	1	
3	Lamp 12V/5-21W	-	-	-	-	GU93450224	1	
4	Rear turn indicator	-	-	-	-	GU27751611	2	
5	Lamp 12V-10W	-	-	-	-	GU93450129	2	
6	Turn indicator lens	-	-	-	-	GU28753750	2	
7	Notched washer	-	-	-	-	GU95022110	2	
8	Nut	-	-	-	-	GU92602411	2	
9	U-bolt	-	-	-	-	GU93301175	1	
10	Rubber spacer	-	-	-	-	GU27741310	1	
11	Nut	-	-	-	-	GU92602206	2	
12	Notched washer	-	-	-	-	GU95021106	2	
13	Washer 6,2X18X1	-	-	-	-	GU95100118	4	
14	Spacer	-	-	-	-	GU91180607	2	
15	Rubber spacer	-	-	-	-	GU91551062	2	

NTX 350 1987-1990	GU056	00	TAB N.
AIR FILTER			

08

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Intake manifold	-	-	-	-	GU19114300	1	
2	Hose clamp	-	-	-	-	GU93305092	1	
3	Pipe	-	-	-	-	GU17114650	1	
4	Rubber pipe 5X9	-	-	-	-	GU00823944050	1	
5	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	1	
6	Air filter support	-	-	-	-	GU19155775	1	
7	Front hose	-	-	-	-	GU19156701	1	
8	Gasket	-	-	-	-	GU19113900	1	
9	Gasket ring	-	-	-	-	GU90706552	2	
10	Rear hose	-	-	-	-	GU19156900	1	
11	Breather pipe	-	-	-	-	GU19156001	1	
12	Ring	-	-	-	-	GU17113450	1	
13	Air filter	-	-	-	-	GU17113651	1	
14	Filter cover	-	-	-	-	GU17114050	1	
15	Support plate	-	-	-	-	GU27114120	1	
16	Washer 5,25x14x1,5	-	-	-	-	GU95100059	1	
17	Nut	-	-	-	-	GU92670305	1	
18	Housing	-	-	-	-	GU31153481	1	
19	Breather	-	-	-	-	GU27159661	1	
20	Hose clamp	-	-	-	-	GU93305018	3	
21	Hose clamp	-	-	-	-	GU61108400	3	
22	Breather	-	-	-	-	GU27159360	1	
23	Pipe	-	-	-	-	GU27157420	1	

NTX 350 1987-1990	GU056	00	TAB N.
FRONT FORK			

09

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Upper U-bolt, black	-	-	-	-	GU27530501	2	
2	Screw M8X30	-	-	-	-	GU98622430	4	
3	Screw	-	-	-	-	GU66530501	2	
4	Lower U-bolt	-	-	-	g	GU27530502	2	
5	Rubber spacer	-	-	-	-	GU27530503	4	
6	Pipe	-	-	-	-	GU27530504	2	
7	Cup	-	-	-	-	GU27530505	2	
8	Nut	-	-	-	-	GU27530506	2	
9	Screw	-	-	-	-	GU66530504	2	
10	Upper plate	-	-	-	r	GU27793115	1	
	Fork head black	-	-	-	g	GU27493170	1	
11	Hex socket screw M8x30	-	-	-	-	GU98682430	4	
12	Plug	-	-	-	-	GU27530575	2	
13	O-ring	-	-	-	-	GU27530576	2	
14	Pipe	-	-	-	-	GU27530577	2	
15	Bottom plate, black	-	-	-	-	GU27494070	1	
16	Nut	-	-	-	-	GU27530509	1	
17	Washer	-	-	-	-	GU27530510	1	
18	Ring nut	-	-	-	-	GU27530511	1	
19	Screw M6X35	-	-	-	-	GU98620335	4	
20	Sleeve	-	-	-	-	GU27525415	2	
21	Spring	-	-	-	-	GU31526636	2	
22	Plunger, complete	-	-	-	-	GU27530578	2	
23	Gasket ring	-	-	-	-	GU27530579	2	
24	Stop ring	-	-	-	-	GU27530580	2	
25	Dust cover	-	-	-	-	GU29524550	2	
26	Washer	-	-	-	-	GU27530582	4	
27	Snap ring	-	-	-	-	GU27530583	2	
28	Gasket ring 40x52x9,5	-	-	-	-	GU27530584	2	
29	Bush	-	-	-	-	GU27530585	2	
30	LH sleeve	-	-	-	r	GU27522615	1	
	LH sleeve	-	-	-	g	GU27522616	1	
31	Screw	-	-	-	-	GU27530523	2	

32	Washer	-	-	-	-	-	GU27530591	2
33	Screw	-	-	-	-	-	GU27530592	2
34	Hose clamp	-	-	-	-	-	GU27530586	2
35	Anti-dust tube	-	-	-	-	-	GU27530530	2
36	Hose clamp	-	-	-	-	-	GU27530587	2
37	RH sleeve	-	-	-	-	r	GU27522515	1
	RH sleeve	-	-	-	-	g	GU27522516	1
38	Stud bolt	-	-	-	-	-	GU27530522	2
39	Washer	-	-	-	-	-	GU27530521	2
40	Self-locking nut	-	-	-	-	-	GU27530520	2
41	Engine oil SAE 20	-	-	-	-	-	GU27530531	10

NTX 350 1987-1990	GU056	00	TAB N.
SWING ARM			


10

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Transmission complete	-	-	-	-	GU31350231	1	
2	Hose	-	-	-	-	GU19327701	1	
3	Hose	-	-	-	-	GU19328801	1	
4	Circlip	-	-	-	-	GU90272023	1	
5	Disc	-	-	-	-	GU19327601	1	
6	Spring	-	-	-	-	GU94321099	1	
7	Coupling	-	-	-	-	GU23328081	1	
8	Protection collar	-	-	-	-	GU23548080	1	
9	Spring	-	-	-	-	GU23548180	1	
10	Hose clamp	-	-	-	-	GU93305074	1	
11	Swing arm	-	-	-	-	GU23540210	1	
12	Pin	-	-	-	-	GU19547000	2	
13	Spacer	-	-	-	-	GU35214300	2	
14	Nut	-	-	-	-	GU14547800	1	
16	Screw	-	-	-	-	GU98620545	1	
17	Washer 10,2x18x2	-	-	-	-	GU95004210	1	
18	Nut	-	-	-	-	GU92602210	1	
19	Cap nut	-	-	-	-	GU92781082	4	
20	Washer 8,4X13X0,8	-	-	-	-	GU14615901	4	
21	Plug	-	-	-	-	GU93180105	2	

NTX 350 1987-1990	GU056	00	TAB N.
ELECTRICAL SYSTEM			

11

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
	Alternator-regulator wiring	-	-	-	S	-	GU27725820	1
1	Electrical system	-	-	-	-	-	GU27747115	1
2	Starter relay	-	-	-	-	-	GU19732500	1
3	Screw	-	-	-	-	-	GU98054212	2
4	Washer	-	-	-	-	-	GU95000205	2
5	Nut	-	-	-	-	-	GU92602205	2
6	Flasher unit	-	-	-	-	-	GU28750561	1
7	Alternator-regulator wiring	-	-	-	B	-	GU27725810	1
8	Dashboard cable	-	-	-	-	-	GU27747215	1
9	Ignition harness	-	-	-	-	-	GU27722115	1
10	Electronic control unit	-	-	-	-	-	GU23721494	2
11	Flexible support	-	-	-	-	-	GU27723835	2
12	Capacitor	-	-	-	-	-	GU27710435	1
13	Taillight wiring harn.	-	-	-	-	-	GU62747320	1
14	Wire	-	-	-	-	-	GU27747815	1
15	Fuse holder box	-	-	-	-	-	GU30743000	1
16	Fuse 15A	-	-	-	-	-	GU28742560	6
17	Brake light switch	-	-	-	-	-	GU39741150	1
18	Nut	-	-	-	-	-	GU92700071	2
19	Neutral indicator extension	-	-	-	-	-	GU19724560	1
20	Wire	-	-	-	-	-	GU18759550	1
21	Hose clamp 3,6x20,6	-	-	-	-	-	GU14609650	1
	Hose clamp	-	-	-	-	-	GU61609630	1
22	Headlight wiring w/harness	-	-	-	-	-	GU14747455	1
23	Alternator wiring BOSCH	-	-	-	B	-	GU23726300	1
24	Notched washer	-	-	-	-	-	GU95021105	2
25	Screw	-	-	-	-	-	GU98054216	2
26	Washer 5,25x14x1,5	-	-	-	-	-	GU95100059	2
27	Washer	-	-	-	-	-	GU95000205	2
28	Nut	-	-	-	-	-	GU92630205	2

		NTX 350 1987-1990		GU056	00	TAB N.	12	
								
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Handlebar	-	-	-	-	GU27600315	1	
2	Clutch lever cpl.	-	-	-	-	GU30605530	1	
3	Starter lever	-	-	-	-	GU27659415	1	
5	U-bolt	-	-	-	-	GU27601015	1	
6	Screw	-	-	-	-	GU27601215	2	
7	Register	-	-	-	-	GU30602500	1	
8	Protection	-	-	-	-	GU27663815	1	
9	LH lights selector	-	-	-	-	GU27738015	1	
10	Handgrip - pair	-	-	-	-	GU19999415	1	
11	Clutch cable	-	-	-	-	GU27093015	1	
12	Throttle cable	-	-	-	-	GU27117515	1	
13	Splitter	-	-	-	-	GU30607910	1	
14	Throttle cable	-	-	-	-	GU27117775	2	
15	Handgrip - pair	-	-	-	-	GU19999415	1	
16	Mobile body	-	-	-	-	GU27603815	1	
17	Steering block	-	-	-	-	GU27604415	1	
18	Throttle	-	-	-	-	GU27738815	1	
19	Adjuster screw	-	-	-	-	GU27603715	1	
20	Cap	-	-	-	-	GU27117615	1	
21	Rearview mirror	-	-	-	-	GU27769475	2	
22	Toolkit	-	-	-	-	GU28929940	1	
23	Shock abs. adj. Wrench	-	-	-	-	GU19912700	1	
24	Operator's handbook	-	-	D	-	GU27900018	1	
	Operator's handbook	-	-	I	-	GU27900015	1	
	Operator's handbook	-	-	UK	-	GU27900016	1	
	Operator's handbook	-	-	F	-	GU27900017	1	

NTX 350 1987-1990	GU056	00	TAB N.
FRONT MUDGUARD			

13

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Front mudguard	-	-	-	g	GU27434416	1	
	Front mudguard	-	-	-	r	GU27434415	1	
2	Mudguard support U-bolt	-	-	-	-	GU27436615	1	
3	Hose clamp	-	-	-	-	GU27651315	4	
4	Ring	-	-	-	-	GU17658260	2	
5	Luggage rack	-	-	-	-	GU27466510	1	
6	Helmet lock	-	-	-	-	GU66466815	1	
7	Rear mudguard	-	-	-	-	GU27437010	1	
8	Support bracket	-	-	-	-	GU27437871	1	
9	Splash guard	-	-	-	-	GU27438716	1	
10	Number plate holder	-	-	-	-	GU01474630	1	
11	Shear rivet	-	-	-	-	GU66468115	2	
12	Screw	-	-	-	-	GU98054325	4	
13	Washer 6,4x12x1,2	-	-	-	-	GU95100141	12	
14	Rubber spacer	-	-	-	-	GU93110060	14	
15	Screw	-	-	-	-	GU98610325	4	
16	Special washer	-	-	-	-	GU61013800	12	
17	Nut	-	-	-	-	GU92601206	4	
18	Screw	-	-	-	-	GU98612312	2	
19	Nut M6x1	-	-	-	-	GU92630106	4	
20	Screw	-	-	-	-	GU98054330	2	
21	Washer	-	-	-	-	GU95000206	4	
22	Screw	-	-	-	-	GU98074314	2	
23	Washer	-	-	-	-	GU95000206	4	
24	Nut M6x1	-	-	-	-	GU92630206	2	
25	Screw	-	-	-	-	GU98200410	4	
26	Washer	-	-	-	-	GU95000204	4	
27	Washer	-	-	-	-	GU95129080	4	
28	Nut	-	-	-	-	GU92602204	4	

NTX 350 1987-1990

GU056

00

TAB N.

14

FOOT RESTS - LATERAL STAND

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	RH cradle arm	-	-	-	gr	GU274203151	1	
2	LH cradle arm	-	-	-	gr	GU274221151	1	
3	Central stand	-	-	-	gr	GU274303151	1	
4	Lateral stand spring	-	-	-	-	GU12434001	2	
5	Screw	-	-	-	-	GU98054530	2	
6	Spacer	-	-	-	-	GU91181114	2	
7	Spring	-	-	-	-	GU94322215	1	
8	Washer	-	-	-	-	GU95000210	3	
9	Nut M10x1,5	-	-	-	-	GU92630510	2	
10	RH Foot rests	-	-	-	-	GU27440210	1	
11	LH Foot rests	-	-	-	-	GU27441310	1	
12	Footrest rubber	-	-	-	-	GU27443210	2	
13	Sump guard	-	-	-	32196C	GU27019610	1	
14	Plate	-	-	-	-	GU27019810	1	
15	Plate	-	-	-	-	GU27019811	1	
16	Screw	-	-	-	-	GU98326014	4	
17	Captive nut	-	-	-	-	GU92660601	4	
18	Screw	-	-	-	-	GU27429515	1	
19	Bush	-	-	-	-	GU19017000	1	
20	Washer	-	-	-	-	GU95007210	5	
21	Nut	-	-	-	-	GU92601210	3	
22	Rear footrest	-	-	-	-	GU27442320	2	
23	LH front footrest guard	-	-	-	-	GU27447520	2	
24	Screw	-	-	-	-	GU98072565	2	
25	Screw	-	-	-	-	GU98820445	2	
26	Spacer	-	-	-	-	GU91180817	2	
27	Spring	-	-	-	-	GU27441110	2	
28	Nut	-	-	-	-	GU92630108	2	
29	Bush 19 mm	-	-	-	-	GU18252050	4	
30	Screw	-	-	-	-	GU98231022	2	
31	Washer 10,5X21X1	-	-	-	-	GU14018400	2	
32	Nut	-	-	-	-	GU92601210	2	



NTX 350 1987-1990


GU056

00

TAB N.

15

REAR BRAKE CALIPER



Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Rear brake caliper	-	-	-	-	GU23653011	1	
2	Pads pair BREMBO	-	-	-	-	GU27654610	1	
3	Clamp	-	-	-	-	GU27655810	1	
4	Bush	-	-	-	-	GU27636010	2	
5	Rod	-	-	-	-	GU27636610	1	
6	Screw	-	-	-	-	GU27636910	1	
7	Silent-block	-	-	-	-	GU27551810	2	
8	Washer	-	-	-	-	GU27636711	2	
9	Nut	-	-	-	-	GU92731100	2	
10	Split pin	-	-	-	-	GU95401218	2	
11	Screw	-	-	-	-	GU27636810	1	
13	Rear brake hose	-	-	-	-	GU27657110	1	
14	Oil pipe screw *	-	-	-	-	GU95990028	2	
15	Gasket	-	-	-	-	GU25656100	4	
16	Screw	-	-	-	-	GU98612422	2	
17	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
18	Brake caliper rev. kit BREMBO	-	-	-	-	GU39659000	1	
19	Pins+spring BREMBO	-	-	-	-	GU39659100	1	
20	Bleeder+cap BREMBO D.6	-	-	-	-	GU65659200	1	

NTX 350 1987-1990	GU056	00	TAB N.	16
FRONT MASTER CILINDER				

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Front master cilinder	-	-	-	-	GU27660115	1	
2	Pump cover	-	-	-	-	GU27661115	1	
3	Brake lever	-	-	-	-	GU27605615	1	
4	Screw	-	-	-	-	GU27664315	1	
5	Pin	-	-	-	-	GU27604815	1	
6	Bracket	-	-	-	-	GU27664075	1	
7	Brake light switch	-	-	-	-	GU27749815	1	
8	Ball	-	-	-	-	GU92295708	1	
9	Cap	-	-	-	-	GU27663615	1	
10	Front brake hose	-	-	-	-	GU27658575	1	
11	Oil pipe screw *	-	-	-	-	GU95990028	1	
12	Gasket	-	-	-	-	GU25656100	2	
13	Front brake caliper	-	-	-	-	GU27652310	1	
14	Pads pair BREMBO	-	-	-	-	GU27654610	1	
15	Brake caliper cover	-	-	-	-	GU30654700	1	
16	Screw	-	-	-	-	GU98612425	2	
17	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
18	Self-tap screw	-	-	-	-	GU99210213	2	
19	Brake caliper rev. kit	-	-	-	-	GU27659010	1	
20	Pin+Brake spring	-	-	-	-	GU30659101	1	
21	Bleeder+cap BREMBO D.10	-	-	-	-	GU31659260	1	
22	Brake mast.cyl rev. kit	-	-	-	-	GU27659315	1	
23	Washer 8,5X18X0,8	-	-	-	-	GU95100251	1	
	Washer 8,5X18X0,5	-	-	-	-	GU95100250	1	

NTX 350 1987-1990	GU056	00	TAB N.
REAR MASTER CYLINDER			

17

Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Brake lever	-	-	-	-	GU27677015	1	
2	Rubber spacer	-	-	-	-	GU30251025	1	
3	Lever	-	-	-	-	GU27667515	1	
4	Spring	-	-	-	-	GU27667615	1	
5	Pump rod	-	-	-	-	GU27675015	1	
6	Rear master cylinder	-	-	-	-	GU27667015	1	
7	Union	-	-	-	-	GU27668015	1	
8	Gasket	-	-	-	-	GU25656100	2	
9	Oil pipe screw	-	-	-	-	GU95990027	1	
10	Brake oil tank	-	-	-	-	GU65663500	1	
11	Tank cap	-	-	-	-	GU17661052	1	
12	Rear brake hose	-	-	-	-	GU00823950050	1	
13	Hose clamp	-	-	-	-	GU19157800	2	
14	Rear brake pump union	-	-	-	-	GU27659515	1	
15	Brake m.cyl seals rev. kit	-	-	-	-	GU27659375	1	
16	Spacer	-	-	-	-	GU27250715	1	
17	Screw M6X45	-	-	-	-	GU98620345	1	
18	Washer 6,4x10x0,7	-	-	-	-	GU14217901	1	
19	Spring washer	-	-	-	-	GU95129260	1	
20	Screw	-	-	-	-	GU98074320	1	
21	Nut	-	-	-	-	GU92601206	1	
22	Screw	-	-	-	-	GU98072330	2	
23	Washer	-	-	-	-	GU95000206	2	
24	Notched washer	-	-	-	-	GU95021106	2	
25	Nut	-	-	-	-	GU92601206	2	
26	Screw	-	-	-	-	GU98054214	2	
27	Washer 5,25x14x1,5	-	-	-	-	GU95100059	2	
28	Hose clamp	-	-	-	-	GU19718000	2	

NTX 350 1987-1990

GU056

00

TAB N.

18

FRONT WHEEL

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Front wheel	-	-	-	-	gg GU27610311	1	
2	Internal spacer	-	-	-	-	GU39615201	1	
3	Bearing	-	-	-	-	GU92204217	2	
4	Flange	-	-	-	-	GU27611210	1	
5	Brake disc	-	-	-	-	GU31613335	1	
6	Screw	-	-	-	-	GU98052470	6	
7	Spring washer 8x15x0,3	-	-	-	-	GU61270300	12	
8	Nut	-	-	-	-	GU92630108	6	
9	Front wheel spindle	-	-	-	-	GU27614110	1	
10	Spacer	-	-	-	-	GU27616310	1	
11	Washer 17X27X2	-	-	-	-	GU95004217	1	
12	Nut M16X1,5	-	-	-	-	GU92602516	1	
13	Front wheel spoke	-	-	-	-	GU27611610	36	
14	Nipples	-	-	-	-	GU27611710	36	
15	Counterweight 10 gr.	-	-	-	-	GU27616110	1	
	Counterweight 15 gr.	-	-	-	-	GU27616111	1	
	Counterweight 20 gr.	-	-	-	-	GU27616112	1	
	Counterweight 30 gr.	-	-	-	-	GU27616113	1	
16	Drift	-	-	-	-	GU19705900	1	

NTX 350 1987-1990	GU056	00	TAB N.
REAR WHEEL			

19

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Rear wheel	-	-	-	-	o	GU27630611	1
	Rear wheel	-	-	-	-	gg	GU27630610	1
2	Brake disc	-	-	-	-	-	GU31613335	1
3	Screw	-	-	-	-	-	GU98230825	6
4	RH rubber coupling	-	-	-	-	-	GU19632501	6
5	LH rubber coupling	-	-	-	-	-	GU19632502	6
6	Bearing	-	-	-	-	-	GU92204218	1
7	Bearing	-	-	-	-	-	GU92204217	1
8	Spacer	-	-	-	-	-	GU27633910	1
9	Spacer	-	-	-	-	-	GU27356910	1
10	Rear wheel spindle	-	-	-	-	-	GU27633310	1
11	Washer	-	-	-	-	-	GU14634400	1
12	Nut M6X1,5	-	-	-	-	-	GU92602316	1
13	Rear wheel spoke, long	-	-	-	-	-	GU27631410	18
14	Rear wheel spoke, short	-	-	-	-	-	GU27631110	18
15	Nipples	-	-	-	-	-	GU27611710	36
16	Counterweight 10 gr.	-	-	-	-	-	GU27616110	1
	Counterweight 15 gr.	-	-	-	-	-	GU27616111	1
	Counterweight 20 gr.	-	-	-	-	-	GU27616112	1
	Counterweight 30 gr.	-	-	-	-	-	GU27616113	1
17	Inner tube fastener	-	-	-	-	-	GU27619110	1

NTX 350 1987-1990	GU056	00	TAB N.
FRONT/REAR SHOCK ABSORBER			

20

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Front fork	-	-	-	-	g	GU27490216	1
	Front fork	-	-	-	-	r	GU27490215	1
2	Shock absorber-pair	-	-	-	-	-	GU31999236	1
3	Pin	-	-	-	-	-	GU23555281	1
4	Pin	-	-	-	-	-	GU23555280	1
5	Spacer	-	-	-	-	-	GU91181407	2
6	Washer	-	-	-	-	-	GU95007210	1
7	Screw	-	-	-	-	-	GU98832420	2
8	Washer	-	-	-	-	-	GU95007208	2
9	Screw	-	-	-	-	-	GU98830416	1
10	Nut	-	-	-	-	-	GU92602411	1
11	Silent-block	-	-	-	-	-	GU27530532	4
12	Tap.roller bearing	-	-	-	-	-	GU92249225	2
13	Clearance washer	-	-	-	-	-	GU14516700	2
14	Dust cover	-	-	-	-	-	GU14517000	2
15	Washer	-	-	-	-	-	GU95100256	1
16	Spacer	-	-	-	-	-	GU27504915	1
17	Cable-guide	-	-	-	-	-	GU27658415	2
18	Ring	-	-	-	-	-	GU27658215	2
19	Screw M6X35	-	-	-	-	-	GU98620335	1
20	Spacer	-	-	-	-	-	GU91180802	1
21	Screw M8X40	-	-	-	-	-	GU98620440	1
22	Notched washer	-	-	-	-	-	GU95022110	1

NTX 350 1987-1990	GU056	00	TAB N.
FRAME			

21

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Frame	-	-	-	-	gr GU274001151	1	
2	Lock	-	-	-	-	GU19782520	1	
3	Rubber spacer	-	-	-	-	GU66103415	2	
4	Screw	-	-	-	-	GU98622420	2	
5	Screw	-	-	-	-	GU98612525	4	
6	Washer	-	-	-	-	GU95120105	4	
7	Nut	-	-	-	-	GU92601210	7	
8	Screw	-	-	-	-	GU98110202	1	
9	Washer	-	-	-	-	GU95007210	6	
10	Plate	-	-	-	-	GU27418215	1	
11	Hex screw M8X16	-	-	-	-	GU98054416	4	
12	Washer	-	-	-	-	GU95000208	4	
13	Drift	-	-	-	-	GU19705900	2	
14	Hex screw M10X55	-	-	-	-	GU98072555	2	
15	Tool kit box	-	-	-	-	GU27914515	1	
16	Cover	-	-	-	-	GU27914615	1	
17	Screw M6x10	-	-	-	-	GU98822310	1	
18	Washer 6,2X18X1	-	-	-	-	GU95100118	1	
19	Rubber spacer	-	-	-	-	GU93110060	1	

NTX 350 1987-1990	GU056	00	TAB N.
DRIVE SHAFT			


22

Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Drive shaft	-	-	-	-	GU31064100	1	
2	Plug	-	-	-	-	GU19065400	1	
3	Connecting rod	-	-	-	-	GU19061521	2	
4	Screw	-	-	-	-	GU19062221	4	
6	Bearing half-shell	-	-	-	-	GU19062022	4	
7	Front main half-bearing	-	-	-	-	GU19065623	2	
8	Rear main half-bearing	-	-	-	-	GU19066522	2	
9	Shoulder	-	-	-	-	GU31066480	2	
10	Piston	-	-	-	-	GU31060400	2	
11	Ring	-	-	-	-	GU19060750	4	
12	Scraper ring	-	-	-	-	GU27061080	2	
13	Piston pin	-	-	-	-	GU19061280	2	
14	Stop ring	-	-	-	-	GU19061320	4	
15	Pistonring set	-	-	-	-	GU27060680	2	
16	Bush	-	-	-	-	GU19061821	2	
17	Screw	-	-	-	-	GU19067700	6	
18	Washer 8,4X13X0,8	-	-	-	-	GU14615901	6	
19	Piston ring	-	-	-	-	GU27060880	2	


NTX 350 1987-1990	GU056	00	TAB N.
FUEL SUPPLY			

23

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Carburettor RH PHBH 28	-	-	-	-	GU27112615	1	
2	Carburettor LH PHBH 28	-	-	-	-	GU27112616	1	
3	RH intake manifold	-	-	-	-	GU31115000	1	
4	LH intake manifold	-	-	-	-	GU31115001	1	
5	Gasket	-	-	-	-	GU19115520	2	
6	Screw	-	-	-	-	GU98310610	2	
7	Washer 6,25x10x1,5	-	-	-	-	GU95100116	2	
8	Screw	-	-	-	-	GU98812325	4	
9	Special washer	-	-	-	-	GU61013800	4	
10	Hose	-	-	-	-	GU19114320	2	
11	Hose clamp	-	-	-	-	GU93305045	4	
12	Gasket ring	-	-	-	-	GU19114680	2	
13	Manifold	-	-	-	-	GU19114480	2	
14	Splitter	-	-	-	-	GU30607910	1	
15	Choke cable	-	-	-	-	GU27132815	2	
16	Choke cable	-	-	-	-	GU27133515	1	
17	Hose clamp	-	-	-	-	GU19718000	1	
18	Washer	-	-	-	-	GU95000205	4	
19	Screw	-	-	-	-	GU98054220	4	
20	Hose clamp 3,6x20,6	-	-	-	-	GU14609650	2	

		NTX 350 1987-1990		GU056		00		TAB N.		24	
GEAR BOX											
											
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.			
1	Primary gear shaft Z=11	-	-	-	-	GU19210520	1				
2	Gear 5a AS Z=22	-	-	-	-	GU19212020	1				
3	Thrust washer mm1	-	-	-	-	GU19215420	5				
4	Circlip	-	-	-	-	GU90271220	5				
5	Gear 4a AS Z=22	-	-	-	-	GU19211820	1				
6	Gear 3a AS Z=18	-	-	-	-	GU19211420	1				
7	Thrust washer	-	-	-	-	GU19214620	1				
8	Gear	-	-	-	-	GU19211320	1				
9	Washer	-	-	-	-	GU19212800	1				
10	Ball bearing	-	-	-	-	GU92201415	1				
11	Clearance washer	-	-	-	-	GU39238100	1				
12	Nut	-	-	-	-	GU10054100	1				
13	Bearing 20X47X14	-	-	-	-	GU92201220	1				
14	Driven shaft	-	-	-	-	GU19213620	1				
15	Spacer	-	-	-	-	GU19212900	1				
16	Bearing 20X47X14	-	-	-	-	GU92201220	1				
17	Spacer	-	-	-	-	GU19213720	1				
18	Gasket ring 18,77X1,78	-	-	-	-	GU90706188	1				
19	Circlip	-	-	-	-	GU90271121	1				
20	Gear	-	-	-	-	GU19214501	1				
21	Gear	-	-	-	-	GU19214820	1				
22	Gear	-	-	-	-	GU19215121	1				
23	Gear	-	-	-	-	GU19215220	1				
24	Gear	-	-	-	-	GU19214001	1				
26	Spacer	-	-	-	-	GU35214300	2				
27	Ball bearing	-	-	-	-	GU92201415	1				
29	Circlip	-	-	-	-	GU90271115	1				
30	Shift cam	-	-	-	-	GU19234420	1				
31	Pin	-	-	-	-	GU19234600	4				
32	Spacer 1 mm	-	-	-	-	GU19355300	1				
33	Snap ring	-	-	-	-	GU90271020	1				
34	Fork AP	-	-	-	-	GU19231220	1				
35	Fork AS	-	-	-	-	GU19231020	2				

36	Roller	-	-	-	-	-	GU92297909	3
37	Pin	-	-	-	-	-	GU95520316	3
38	Pre-selector kit	-	-	-	01397N	-	GU20999520	1
39	Spring	-	-	-	01397N	-	GU28238261	1
	Spring	-	-	-	-	-	GU60238200	1
40	Spacer	-	-	-	01397N	-	GU20208520	1
	Bush	-	-	-	-	-	GU91182010	1
41	Shift lever	-	-	-	-	-	GU19258220	1
42	Screw	-	-	-	-	-	GU98072325	2
43	Notched washer	-	-	-	-	-	GU95021106	2
44	Tie rod	-	-	-	-	-	GU18257950	1
45	Fork	-	-	-	-	-	GU12629800	1
46	Nut	-	-	-	-	-	GU95602206	2
47	Washer	-	-	-	-	-	GU95129110	1
48	Ball joint	-	-	-	-	-	GU18258101	1
49	Split pin	-	-	-	-	-	GU95500222	1
50	Pin	-	-	-	-	-	GU95770265	1
51	Lever	-	-	-	-	-	GU19256920	1
52	Spring washer	-	-	-	-	-	GU60013800	1
53	Nut M6x1	-	-	-	-	-	GU92630106	1
54	Gear lever	-	-	-	-	-	GU27250815	1
55	Rubber spacer	-	-	-	-	-	GU30251025	1
56	Spring washer	-	-	-	-	-	GU95129260	1
57	Idle gear Z=25	-	-	-	-	-	GU27211111	1
58	Nut	-	-	-	-	-	GU10054100	1
59	Clearance washer	-	-	-	-	-	GU39238100	1
60	Change gear tie rod compl.	-	-	-	-	-	GU19257701	1
61	Spacer	-	-	-	-	-	GU27250715	1
62	Fork	-	-	-	2A	-	GU28258160	2
63	Stud bolt	-	-	-	2A	-	GU27257715	1
64	Washer	-	-	-	2A	-	GU95000206	1
65	Nut M6x1	-	-	-	2A	-	GU92630106	2
66	Washer	-	-	-	-	-	GU19214320	4
67	Bush	-	-	-	-	-	GU19266720	1

		NTX 350 1987-1990		GU056		00		TAB N.		25
CARBURETTORS										
										
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.		
1	Gas valve 30	-	-	-	-	GU27934820	2			
2	Conical pin 19-2a	-	-	-	-	GU23937710	2			
3	Needle valve	-	-	-	-	GU27935520	2			
4	Main jet	-	-	-	-	GU17935767	2			
5	Idle jet 42	-	-	-	-	GU23935910	2			
6	Starter jet 60	-	-	-	-	GU19936000	2			
7	Needle valve	-	-	-	-	GU19934600	2			
8	Float gr.9,5	-	-	-	-	GU27934315	2			
10	Wire tensioner screw	-	-	-	-	GU12937200	2			
11	Screw	-	-	-	-	GU14934650	2			
12	Cover	-	-	-	-	GU19935080	2			
13	Gas valve return spring	-	-	-	-	GU19937180	2			
14	Plate	-	-	-	-	GU19938580	2			
15	Conical pin clip	-	-	-	-	GU65933600	2			
18	Plug with OR	-	-	-	-	GU10933700	2			
19	Gaskets set	-	-	-	-	GU19939980	2			
20	Nut	-	-	-	-	GU19938880	4			
21	Screw	-	-	-	-	GU13937900	2			
22	Starter device cover	-	-	-	-	GU17937450	2			
25	Starter valve	-	-	-	-	GU13937800	2			
26	Adj.min.eng.speed screw	-	-	-	-	GU13936200	2			
27	Spring	-	-	-	-	GU13936300	2			
28	Flat washer	-	-	-	-	GU65933700	2			
30	Gas valve adjuster screw	-	-	-	-	GU13936600	2			
31	Spring	-	-	-	-	GU13936700	2			
32	Flat washer	-	-	-	-	GU14931650	2			
35	Fuel filter	-	-	-	-	GU43934000	2			
36	Fuel pipe union cap	-	-	-	-	GU13934600	2			
38	Cap fixing screw	-	-	-	-	GU10934900	2			
41	Aluminium float chamber	-	-	-	-	GU19934480	2			
	Float chamber plastica	-	-	-	03399N	GU31934460	2			
42	Float pin	-	-	-	-	GU13933100	2			

NTX 350 1987-1990	GU056	00	TAB N.
CRANKCASE			

26

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Crankcase	-	-	-	-	GU31000100	1	
2	Stud bolt	-	-	-	-	GU96451560	4	
3	Stud bolt	-	-	-	-	GU96451430	4	
4	Stud bolt	-	-	-	-	GU96508055	2	
5	Bush	-	-	-	-	GU19015020	4	
6	Spring washer 8x15x0,3	-	-	-	-	GU61270300	6	
7	Nut	-	-	-	-	GU92601208	6	
8	Union	-	-	-	-	GU19003800	1	
9	Bush 6,6x9x13	-	-	-	-	GU19002020	2	
10	Plug	-	-	-	-	GU19016320	1	
11	Gasket ring	-	-	-	-	GU90401530	1	
13	Gasket ring	-	-	-	-	GU90405367	1	
14	Timing system cover	-	-	-	-	GU31001431	1	
15	Gasket	-	-	-	-	GU19001200	1	
16	Screw	-	-	-	-	GU98610325	22	
17	Plug	-	-	-	-	GU19017120	1	
18	Gasket ring 28x38x7	-	-	-	-	GU90402840	1	
19	Motor oil cup	-	-	-	-	GU23003510	1	
20	Gasket	-	-	-	-	GU19003602	1	
21	Oil plug	-	-	-	-	GU95980213	1	
22	Gasket	-	-	-	-	GU10528900	1	
23	Hex socket screw M6x18	-	-	-	-	GU98610335	5	
24	Cover	-	-	-	-	GU27001636	1	
25	Flange	-	-	-	-	GU27001136	1	
26	Plug	-	-	-	-	GU31003431	1	
27	O-ring	-	-	-	-	GU90706444	1	
28	Oil filler plug	-	-	-	-	GU19004920	1	
29	Gasket ring	-	-	-	-	GU90706282	1	
30	Oil filler plug	-	-	-	-	GU28004950	1	
31	Gasket 20,1x28x2	-	-	-	-	GU95100709	1	
32	Bolt	-	-	-	-	GU98072490	1	
33	Gasket 8,25x15x1	-	-	-	-	GU12154200	1	
34	Oil seals - set	-	-	-	-	GU31999565	1	

35	Engine set gasket	-	-	-	-	-	GU19999080	1
36	Column nut	-	-	-	-	-	GU92660010	4
37	Screw M6x30	-	-	-	-	-	GU98610330	2
38	Washer 10,5X18X0,8	-	-	-	-	-	GU95129180	4
39	Gasket	-	-	-	-	-	GU31016900	1
40	Rubber spacer	-	-	-	-	-	GU19007700	1
41	Engine w/o gearbox, blank	-	-	-	-	-	GU27991035	1

NTX 350 1987-1990

GU056

00

TAB N.

27

CYLINDER HEAD

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	RH cylinder head	-	-	-	-	GU23022170	1	
2	LH cylinder head	-	-	-	-	GU23022270	1	
3	Valve guide	-	-	-	-	GU61036801	4	
4	Snap ring	-	-	-	-	GU90353009	4	
5	Stud bolt	-	-	-	-	GU96506042	4	
6	Anti-vibration plate	-	-	-	-	GU19025300	4	
7	Nut	-	-	-	-	GU23021910	2	
8	Oil seal	-	-	-	-	GU19037820	4	
9	Valves cover	-	-	-	-	GU31023531	2	
10	Gasket	-	-	-	-	GU19023700	2	
11	Column nut	-	-	-	-	GU92660010	4	
12	Nut	-	-	-	-	GU31021900	4	
13	Washer 10,5X18X0,8	-	-	-	-	GU95129180	4	
14	Long tie rod	-	-	-	-	GU96510177	4	
15	Short tie rod	-	-	-	-	GU96510120	4	
16	Hex socket screw M6X25	-	-	-	-	GU98622325	12	
17	Cylinder with piston	-	-	-	-	GU31060100	2	
18	Bush	-	-	-	-	GU19021320	2	
19	Gasket	-	-	-	-	GU27022080	2	
20	Tie rod	-	-	-	-	GU96500102	2	
21	Spring washer 8x15x0,3	-	-	-	-	GU61270300	2	
22	Plug	-	-	-	-	GU93180245	4	
23	O-ring	-	-	-	-	GU61027200	2	
24	Gasket	-	-	-	-	GU27020820	2	
25	O-ring	-	-	-	-	GU90706076	2	

NTX 350 1987-1990

GU056


00

TAB N.

28

TIMING SYSTEM

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Intake valve	-	-	-	-	GU19036082	2	
2	Exhaust valve	-	-	-	-	GU19036183	2	
3	Spring	-	-	-	-	GU61037600	4	
4	Spring	-	-	-	-	GU61037500	4	
5	Upper cup	-	-	-	-	GU61038000	4	
6	Half-cone	-	-	-	-	GU61038100	8	
7	Rocker arm assy.	-	-	-	-	GU19030500	4	
8	Screw	-	-	-	-	GU19034000	4	
9	Nut M6x1	-	-	-	-	GU92602406	4	
10	Rocker shaft	-	-	-	-	GU19032080	2	
11	Thrust washer	-	-	-	-	GU19032380	4	
12	Circlip	-	-	-	-	GU90271018	4	
13	Lower cup	-	-	-	-	GU61037000	4	
14	Spacer	-	-	-	-	GU19032980	4	
15	Hose	-	-	-	-	GU19027500	2	
16	Camshaft	-	-	-	-	GU27053362	1	
17	Timing system gear	-	-	-	-	GU19054521	1	
18	Bolt	-	-	-	-	GU61054900	2	
19	Camshaft chain	-	-	-	-	GU19058021	1	
20	Chain stretching drive	-	-	-	-	GU19058220	1	
21	Screw	-	-	-	-	GU98822316	1	
22	Washer	-	-	-	-	GU95129115	1	
23	Sector	-	-	-	-	GU19055700	2	
24	Snap ring	-	-	-	-	GU90353029	1	
25	Tappet	-	-	-	-	GU19045861	4	
26	Rocker arm rod	-	-	-	-	GU31045000	4	
27	Roller	-	-	-	-	GU95512035	1	
28	Safety washer	-	-	-	-	GU23217800	2	

		NTX 350 1987-1990		GU056		00		TAB N.		29
CLUTCH										
										
Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.		
1	Clutch control	-	-	-	-	GU19080161	1			
2	New cup type	-	-	-	-	GU19083462	1			
3	Snap ring	-	-	-	-	GU90272075	1			
4	Driven clutch disc	-	-	-	-	GU27084420	1			
5	Chain ring MOTOPLAT	-	-	-	-	GU19067900	1			
6	Washer 6,4x10x0,7	-	-	-	-	GU14217901	6			
7	Hex screw M6X16	-	-	-	-	GU98054316	6			
8	Rod	-	-	-	-	GU20085720	1			
9	Inner body	-	-	-	-	GU14086000	1			
10	Thrust bearing	-	-	-	-	GU12087001	1			
11	Outer body	-	-	-	-	GU14086100	1			
12	O-ring 17,13x2,62	-	-	-	-	GU90706170	1			
13	Clutch relese shaft	-	-	-	-	GU14090201	1			
14	Adjuster screw	-	-	-	-	GU14090400	1			
15	Nut M8X1	-	-	-	-	GU92602508	1			
16	Lever return spring	-	-	-	-	GU94321105	1			
17	Pin 7x39	-	-	-	-	GU95780271	1			
18	Split pin	-	-	-	-	GU95500222	1			
19	Gasket ring 28x40x7	-	-	-	-	GU90402841	1			
20	Gasket ring	-	-	-	-	GU27210710	1			
21	Gasket ring 6x16x7	-	-	-	-	GU90400616	1			
22	Spacer	-	-	-	-	GU19213720	1			
23	Gasket ring 18,77X1,78	-	-	-	-	GU90706188	1			
24	Nut	-	-	-	-	GU19356700	1			
26	Clutch drum	-	-	-	-	GU31200401	1			
27	Plug	-	-	-	-	GU93180220	1			
28	Bearing	-	-	-	-	GU90201220	1			
29	Bearing fixing plate	-	-	-	-	GU19203420	1			
30	Screw	-	-	-	-	GU98054314	3			
31	Washer 6,4x10x0,7	-	-	-	-	GU14217901	3			
32	Screw M6x30	-	-	-	-	GU98610330	11			
33	Screw	-	-	-	-	GU98610435	3			
34	Screw	-	-	-	-	GU98620450	1			
35	Spring washer 8x15x0,3	-	-	-	-	GU61270300	6			
36	Nut	-	-	-	-	GU92601208	1			

NTX 350 1987-1990

GU056

00

TAB N.

30

EXHAUST UNIT

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	RH exhaust pipe	-	-	-	-	GU27120715	1	
2	LH exhaust pipe	-	-	-	-	GU27120716	1	
3	Expansion chamber	-	-	-	-	GU27123915	1	
4	Silencer	-	-	-	-	GU27122915	1	
5	Exhaust pipes cover	-	-	-	-	GU27121915	1	
6	Ring nut	-	-	-	-	GU61025100	2	
7	Spacer	-	-	-	-	GU61025400	4	
8	Gasket	-	-	-	-	GU19025280	2	
9	Nut	-	-	-	-	GU92701062	4	
10	Special washer	-	-	-	-	GU61013800	4	
11	Hose clamp	-	-	-	-	GU27123415	2	
12	Screw	-	-	-	-	GU98822416	2	
13	Spring washer 8x15x0,3	-	-	-	-	GU61270300	1	
14	Washer	-	-	-	-	GU95000208	1	
15	Screw	-	-	-	-	GU98290608	2	
16	Hose clamp	-	-	-	-	GU27123415	1	
17	Rubber spacer	-	-	-	-	GU27126615	1	

NTX 350 1987-1990	GU056	00	TAB N.
OIL PUMP-FILTER			

31

Pos.	Description	Year	I_M_	Country	Version	Code	Q.ty	P.Cod.
1	Oil pump	-	-	-	-	GU19146422	1	
3	Roller bearing 10x22x20	-	-	-	-	GU92252210	1	
4	Oil pump shaft assy.	-	-	-	-	GU19147820	1	
5	Inner rotor	-	-	-	-	GU19148420	1	
7	Guide roller	-	-	-	-	GU92296726	1	
8	Ball	-	-	-	-	GU92295911	1	
9	Pressure sensor	-	-	-	02201N	GU31999581	1	
10	Plug	-	-	-	-	GU12159000	1	
11	Screw M6X35	-	-	-	-	GU98620335	3	
12	Pin	-	-	-	-	GU19018920	2	
13	Oil filter	-	-	-	-	GU19152200	1	
14	Screw	-	-	-	-	GU98054314	1	
15	Plate	-	-	-	-	GU95187006	1	
16	Oil filter	-	-	-	-	GU19153000	1	
17	Oil valve cpl.	-	-	-	-	GU10158201	1	
18	Valve body	-	-	-	-	GU10158701	1	
19	Piston	-	-	-	-	GU12150900	1	
20	Valve spring	-	-	-	-	GU94321072	1	
21	Bottom	-	-	-	-	GU12150700	1	
22	Washer 14,5X20X1	-	-	-	-	GU95100523	2	
23	Oil pump gear	-	-	-	-	GU19147721	1	
24	Washer 10,5x16x1	-	-	-	-	GU19149800	1	
25	Nut M10x1,25	-	-	-	-	GU92602510	1	

NTX 350 1987-1990

GU056

00

TAB N.

32

TRANSMISSION CAGE

Pos.	Description	Year	I_M	Country	Version	Code	Q.ty	P.Cod.
1	Box cover	-	-	-	-	GU31200801	1	
2	Bearing 15x35x11	-	-	-	-	GU92204215	2	
3	Gasket ring 28x40x7	-	-	-	-	GU90402841	1	
4	O-ring 13,95x2,92	-	-	-	-	GU90706140	1	
5	Plate	-	-	-	-	GU19213820	1	
6	Screw	-	-	-	-	GU98622314	4	
7	Washer 6,4x10x0,7	-	-	-	-	GU14217901	6	
8	Plate	-	-	-	-	GU19235800	1	
9	Screw	-	-	-	-	GU98622314	2	
10	Gasket	-	-	-	-	GU19200320	1	
11	Sensor	-	-	-	-	GU19207220	1	
12	Gasket 8,25x15x1	-	-	-	-	GU12154200	1	
13	Screw M12x1,25	-	-	-	-	GU19237800	1	
14	Low nut M12x1,25	-	-	-	-	GU92602512	1	
15	Gasket	-	-	-	-	GU19201120	1	
16	Bush 6,6x9x13	-	-	-	-	GU19002020	4	
17	Transmission cage	-	-	-	-	GU31200201	1	
18	Screw M6x30	-	-	-	-	GU98610330	7	
19	Screw	-	-	-	-	GU98610435	4	
20	Pawl	-	-	-	-	GU55234700	1	
21	Lever return spring	-	-	-	-	GU94321067	1	
22	Breather plug	-	-	-	-	GU31206500	1	
23	Gasket	-	-	-	-	GU10528900	2	
24	Oil filler plug	-	-	-	-	GU31351200	1	
25	O-ring 20,24X2,62	-	-	-	-	GU90706203	1	
26	Oil plug	-	-	-	-	GU95980213	1	
27	Oil bulhead	-	-	-	-	GU19208220	1	
28	Ball bearing 20x42x12	-	-	-	-	GU92201120	1	
29	Transmission assy and housing	-	-	-	-	GU27991515	1	